


KP 安装方法 ( 包括 KP 一代/KP 二代所有版本 ):

1 拷贝DK\_System和“KindlePaperwhite\_安装法”文件夹下的bin文件到根目录，拷贝完后kindle磁盘根目录截图如下：




2 拔掉usb，拷贝kindle主目录点击menu选择设置，再次点击menu选择"更新您的kindle"，自动更新成功后，起来后即是新版本；

两次menu菜单如下：



Cloud | **On Device**



**Vocabulary  
Builder**

Shop Kindle Store

List View

Create New Collection

Sync and Check for Items

**Settings**

Experimental Browser

Discover new titles in the  
Kindle Store

> Tap Here





### Settings

#### Airplane Mode

Turn on Airplane Mode to disconnect from all wireless networks.

#### Wi-Fi Networks

Join a Wi-Fi network for faster internet access.  
Available Wi-Fi Networks: 35  
Not Connected

#### Registration

This device and any content purchased from the Amazon Store are registered to the Amazon account.  
Registered User: Steve zuo

#### Device Options

Manage your Kindle passcode, screen timeout, display language, dictionaries, and personalize your Kindle.

#### Reading Options

Manage Vocabulary Builder, annotations, popular highlights, page refresh, and social networks.

### Shop Kindle Store

**Update Your Kindle**

Restart

Reset Device

Device Info

Legal

Sync and Check for Items

如果"更新您的kindle"选项置灰不可用，第二步操作点击重启也可以，重启过程中会报ERROR4错误，不用担心，此时短按关机键会自动重启

备注：部分机型重启过程中可能会报ERROR3错误，不用担心，此时短按关机键会自动重启